### **AVION WATER COMPANY, INC.**

#### 60813 PARRELL RD BEND OR 97702

TELEPHONE (541) 382-5342 FAX (541) 382-5390

### INSTALLATION GUIDELINES

Revised July 2011

FOR SMALL DOUBLE CHECK VALVE ASSEMBLIES (DCVA's) BELOW GROUND LEVEL ON AVION DOMESTIC SERVICE LINES.


If, for any reason, you're unable to comply with #1 through #6, you must have prior authorization from Avion. While the hole is still exposed, call our office & request one of our servicemen to meet with you & give their approval.

- 1. The DCVA must be installed on the domestic line as close as is practical to the water meter. No other plumbing installations are allowed in between the meter & DCVA on the domestic line.
- 2. The DCVA must be installed with the test cocks facing up.
- 3. Must use a box size with a lid that measures 20" X 14" (which is commonly referred to as a Jumbo Meter Box) with a 6" Jumbo Extension on top. Anyone using a standard size box & extension without prior Avion approval will be required to replace them with a jumbo size. Boxes or extensions made of treated wood, concrete or anything other than plastic are not acceptable.
- 4. The DCVA must be installed at a depth of 14". See diagram on the back of this page. Avion Water Co. Inc. uses both a Jumbo Meter Box & a Jumbo 6" Extension to obtain this depth.
- 5. The DCVA must be up in the box & centered in the middle with a 2" minimum space below the DCVA so it's not sitting in the dirt below box.
- 6. The Jumbo meter box & 6" extension must be set to ground level.
- 7. Sufficient drainage must be provided to prevent the DCVA from being submerged.
- 8. Avion shall inspect the installation prior to the assembly being put into service. Call our office & request an inspection after installing. Avion Water Company will inspect the installation at no charge.
- 9. The Oregon Administrative Rules 333-061-0070 state that after a DCVA is installed, the assembly shall be tested before use and annually thereafter. Avion will do the first test at the time of inspection at no charge.
  - Information regarding our Cross Connection Program (CCP) will be provided for annual testing of the DCVA.

## FOR RETRO FIT DCVA INSTALLATION

### NOTE:

THE DCVA MAY NEED TO BE A
DIFFERENT DEPTH THAN THE WATER
METER, TO MEET CURRENT STANDARDS,



# OREGON PLUMBING CODE DOESN'T ALLOW: PVC THREADED FEMALE FITTINGS

revised installation guidelines, 03/26/08